

## Wheel Stops

### *Car Park Traffic Calming*

Wheel stops are used to limit the travel of vehicles when manoeuvring into a parking space. Wheel stops restrict vehicle encroachment into pedestrian areas or other parking spaces and prevent nuisance impacts with barriers.

It is recommended that wheel stops be used whenever the vertical drop to a lower level is between 150mm and 600mm.

### Specifications

- Wheel stop length: 1650mm.
- Wheel stop height: 100mm.
- Width (at bottom of wheel stop): 150mm.
- Wheel stop mass: 16kg.
- Manufactured to the recommendations of AS/NZS 2890.1: Parking Facilities (Part 1: Off-street Car Parking).
- Number of anchor bolts per wheel stop: 3.

